

# INSTRUCTION MANUAL

## Automatic Tool Changer

### NITTAOMEGA type L

#### NOTICE

##### For use of this document:

Please keep this document always readily available to those who use the product. If you need an additional copy, please download the document from our website: <http://www.nitta.co.jp/>

## Nitta Corporation

---

Osaka HQ: 4-4-26 Sakuragawa, Naniwa-ku, Osaka, Osaka 556-0022

Tel: +81 6-6563-1273

FAX: +81 6-6563-1274

Tokyo Branch: 8-2-1 Ginza, Chuo-Ku, Tokyo 104-0061

Tel: +81-3-6744-2708

FAX: +81-3-6744-2709

Nagoya Branch: 1-17-23 Meieki-Minami, Nakamura-ku, Nagoya 450-0003

Tel: +81-52-589-1310

FAX: +81-52-586-5707

Nabari Plant: 1300-45 Yabata, Nabari, Mie 518-0494

Tel: +81-595-64-2916

FAX: +81 595-63-9527

Issued: April 2021

Revised:

Ver. No.: rev.0

# Contents

<b>Preface</b> .....	<b>I</b>
<b>Notice</b> .....	<b>I</b>
<b>Product Warranty</b> .....	<b>I</b>
<b>Unpacking and Check</b> .....	<b>I</b>
<b>Safety Precautions</b> .....	<b>II</b>
<b>1. Overview of the Automatic Tool Changer (ATC)</b> .....	<b>1</b>
1-1. Robot Side .....	1
1-1-1. Robot Adaptor.....	1
1-1-2. Selection of Input Device.....	2
1-1-3. Robot adaptor plate (optional) .....	3
1-2. Tool Side .....	3
1-2-1. Tool Adaptor.....	3
1-2-2. Tool Adaptor Plate (Optional).....	3
1-3. Option.....	3
<b>2. Configuration:</b> .....	<b>4</b>
<b>3. Standard Specifications</b> .....	<b>5</b>
3-1. Common Specifications .....	5
3-2. ATC.....	6
3-2-1. ATC Specifications .....	6
3-2-2. Internal Power Wire for ATC .....	7
3-2-3. Coupling Check End Sensor.....	7
3-2-4. Chuck and Unchuck Sensor .....	8
3-2-5. LED ASSY Specifications .....	8
3-2-6. Precautions for Allowable Load and Installation .....	9
3-2-7. Allowable Electric Load.....	9
3-3. Spot Welding Module (Seal Connector Specifications) .....	10
3-3-1. Spot Welding Module Specifications.....	10
3-3-2. Power Wire for Spot Welding Module (Power).....	11
3-3-3. Internal Power Wire for Spot Welding Module (Earth) .....	11
3-4. Spot Welding Module (Direct Cabling Specifications) .....	12
3-5. Servo Motor Module .....	13
3-5-1. Servo Motor Module Specifications .....	13
3-5-2. Internal Power Wire for Servo Motor Module.....	14
3-6. Hydraulic Module .....	15

---

3-7. Pneumatic Module.....	16
3-7-1. 4 Ports type specifications.....	16
3-7-2. 8 Ports type specifications.....	17
3-8. Signal module .....	18
3-9. Fall Prevention System.....	19
<b>4. Part Names .....</b>	<b>20</b>
<b>5. Procedures of Installation to Robot/Tool.....</b>	<b>21</b>
5-1. Robot Adaptor .....	21
5-2. Tool Adaptor .....	21
5-3. Connecting to Fitting/Removal Port .....	23
5-4. Electric Wiring.....	25
5-5. Cable Fixing.....	25
5-6. ATC Grease up.....	26
5-7. Precautions for Installing ATC to a Tool.....	27
5-7-1. ATC Orientation.....	27
5-7-2. Precautions for using a servo motor for a tool .....	27
5-8. Procedure for Installing Module to ATC .....	28
5-8-1. Module Mounting Bolts .....	28
5-8-2. Wiring for Spot Welding Module of Direct Cabling Specifications.....	29
5-8-3. When a Servo Motor Module is used: .....	33
5-8-4. When a hydraulic module is used: .....	34
5-8-5. When a pneumatic module is used: .....	35
5-8-6. When a Signal Module is used: .....	35
5-8-7. When a Fall Prevention System Is Used: .....	35
<b>6. Operations and Programming .....</b>	<b>36</b>
6-1. Checking before Teaching (Robot Operations) .....	36
6-2. Operations and Programming .....	37
6-3. Basic Flow of ATC.....	38
6-4. Interlocking around ATC .....	39
6-5. Precautions for Operations .....	40
6-6. Points to Check during Line Downtime (or Line Uptime).....	42
6-7. Emergency Response Actions .....	43
6-7-1. Response Actions to Interference or Crash .....	43
6-7-2. Response Action to Water Exposure .....	43
6-7-3. Precautions for Transportation.....	44

## Preface

Thank you for choosing Nitta Automatic Tool Changer (hereafter referred to as "ATC").

This document provides precautions for handling, detailed descriptions of the specifications and mandate inspection and maintenance items for secure applications and appropriate maintenance and inspection of the system, focusing on mechanical sections of ATC.

Therefore, those in charge of introduction line planning, maintenance and inspection, unpacking or actual operations of the product must read this document and fully understand the ATC before use.

Ensure that this document is securely delivered to end users of this product.

- All rights reserved.
- External appearance and specifications described in this document are subject to change for improvement.
- Be sure to read this document carefully before working on the product.
- Be sure to confirm whether workers are required to be sufficiently trained for applicable expertise.
- Take note that we assume no responsibility regarding any damage or accident that occurs in works performed by customers.

## Notice

This document is only intended for customers of Nitta Corporation (hereinafter referred to as "the company").

Technical information and drawings presented in this document are proprietary of the company and it is prohibited to publish all or part of this document for any commercial purpose or disclose the same to any third party without prior written consent of the company.

The contents of this document are subject to change without any prior notice. The delivered product may not be the same as figures and photos contained herein due to any later change in specifications.

## Product Warranty

- Warranty period  
1 year from the delivery date of this product or 3,000 hours of operation, whichever comes first.
- Warranty subject  
Any genuine part of the product exhibiting defect in material or manufacturing will be fixed or serviced without charge within the warranty period.
- Exclusion  
Items listed below are excluded from warranty:
  - (1) Any failure and accident arising out of user's negligence
  - (2) Consumables
  - (3) Any failure caused by natural disaster, accident, fire, theft or unauthorized use, etc.
  - (4) Any failure or accident arising out of non-conformity to maintenance and inspection instructions set forth in this document and the maintenance and inspection procedures
  - (5) Any failure or accident arising out of repair, adjustment, or alteration performed by other than Nitta engineers
  - (6) Any failure caused by any use of used parts

Any secondary damage such as line stoppage due to a system failure or damage arising out thereof is also out of the warranty coverage.

## Unpacking and Check

Although we exercise thorough care to eliminate wrong delivery before shipment, please check the following items when you unpack the product for confirmation. Should there be any defect or missing item, please contact our office indicated in the cover page of this document.

- Please check that mounting bolts are included. (See the relevant delivery specifications.)
- Please check the spare parts. (To be determined in separate meetings.)
- For details of options, e.g. special modules, please feel free to contact us.






## Safety Precautions

### For Safe Use of the Product

#### a) Hazard, warning and cautions indications in this document

This section describes safety precautions for proper use of the Nitta product and prevention of injuries and property damages. These precautions are classified into three levels according to severity of potential hazards and damages that may be caused by non-conformity thereto.

#### Indications in this document

 <b>DANGER</b>	Improper use disregarding this indication may lead to a hazardous situation which may result in death or serious injury and requires urgent alerting when such hazard is materialized.
 <b>WARNING</b>	Improper use disregarding this indication may lead to a hazardous situation which may result in death or serious injury.
 <b>CAUTION</b>	Improper use disregarding this indication may lead to a hazardous situation which may result in minor injury or property damage.
 <b>Referenc</b>	This indicates use examples, etc.
 <b>MEMO</b>	This indicates special instructions less important than cautions.

Please note that a severe accident may occur depending on situations even when instructions in the indications are observed. Please strictly observe the instructions.

#### Disclaimer

- (1) We assume no responsibilities for any damage arising out of any failure caused by intention or negligence of customer (including software malfunction), or any reason not attributable to Nitta, such as an accident or natural disaster.
- (2) We assume no responsibilities for any damage caused by any use not described or prescribed in our catalogs (including the instruction manual).
- (3) We assume no responsibilities for any failure alleged to be warrantable by customers if there is no clear evidence of our responsibility.
- (4) We assume no responsibilities for any incidental damage arising out of use of or inability to use our product (including but not limited to loss of business profit and business interruption).

#### b) Introduction

ATC does not work alone and is only usable when being equipped on a robot and a compatible unit. For increased safety of the entire system, it is necessary to consider not only the single ATC but also the robot system and compatible unit system as a whole.

#### **DANGER**

For use of ATC, be sure to observe safety instructions concerning core robots and compatible units. For any work within the robot safety fence, consider preparing a safety system design to shut down power over 50V once any person gets into the fenced area.

**c) General Precautions**

---

**⚠ CAUTION**

Personnel engaged in installation, programming and maintenance works inside the robot safety fence for the ATC must have expertise in robot operations (having completed expert training). In addition, those engaged in disassembly or assembly works of the ATC, whether in or out of the safety fences, shall read this document, installation guide, and maintenance procedures.

---

**⚠ WARNING**

For works in the safety fence area, be sure to wear appropriate clothing for the work with personal protective equipment such as a hard hat, safety boots, etc. For internal disassembly works for the ATC, use protective glasses for protection against pop-out parts.

---

**⚠ WARNING**

Do not use this product in any of the environments listed below. Otherwise, operators may be injured.

- Flammable environment (containing highly volatile and flammable substances)
- Environment with explosive atmosphere (e.g. combustible gas and chemical spattering)
- Environment exposed to water/water drops or highly humid environment
- Environment with corrosive atmosphere
- Environment with high degree of radiation

When the product is used under any of the above environment, we assume no responsibility for any failure or damage.

Also, malfunction may occur in an environment with spattering dust, chip and cutting oil, etc.

---

**⚠ WARNING**

Do not disassemble or reassemble any parts other than those mentioned in this manual. A serious accident such as a fall may occur.

---

**d) Precautions for Installation**

---

**⚠ WARNING**

For installation of the ATC, remove the pertinent product and place it out of the robot safety fence as long as possible so that installation can be performed securely.

---

**⚠ DANGER**

If installation work is performed inside the safety fence, securely shut off the power over 50V from the ATC and ensure that the robot is securely stopped before entering into the fence area.

---

- 
- ⚠ DANGER** Be sure to check the following items before starting the installation procedure:
- (a) Welding power source, control power source and driving power source are shut off before work.
  - (b) All hydraulic, pneumatic, and water pressure sources are off before work.
  - (c) All residual hydraulic, pneumatic, and water pressure is released before work.
  - (d) Note that some connectors and cables may be hot depending on their specifications.
- 
- ⚠ DANGER** Turning the power supply or hydraulic/pneumatic/water pressure source ON during the installation work without notifying the operator(s) may create an extremely dangerous situation. Establish a procedure to always prevent such events for safety in work areas.
- 
- ⚠ WARNING** Use positioning pins when you put the ATC on robots and tools. If it is installed without using the positioning pin, the position may move to wrong position during use, the ATC cannot be connected and separated reliably, and a serious accident such as dropping may occur. If the positioning pins are unavoidable, the customer should take measures to prevent the tool from falling due to abnormal chucking or unchucking.
- 
- ◆ MEMO** Example of countermeasures when the positioning pin cannot be used
- Perform daily inspections (checking misalignment, scratches or abnormalities on each part such as taper pin, bush, cam, lock parts, grease application)
  - Slow down the chucking / unchucking operation as much as possible
  - Reliably capture the interlock signal.
- Especially for the presence sensor of the stand, move to the next step after confirming that the presence sensor of the tool is in the ON.
- 
- ⚠ CAUTION** Be sure to install specified parts. In addition, when you replace parts, install parts to their original positions and be sure to perform inspections in accordance with certain procedures.
- 
- ⚠ WARNING** Ensure that the rated load (moment torque) does not exceed product's rated value. Otherwise, not only the product functionality and life may be adversely affected but also unexpected accident may occur.
- 
- ⚠ WARNING** Ensure that the electric load applied to the signal pin and electrode does not exceed the rated voltage and allowable current. Otherwise, not only the product functionality and life may be adversely affected but also unexpected accident may occur.
- 
- ⚠ WARNING** Supply water and air to hydraulic/pneumatic, fall prevention system, and ATC chuck/unchuck ports so as to maintain pressure within the rated range. Otherwise, not only the product functionality and life may be adversely affected but also unexpected accident may occur.
-

---

**⚠ WARNING** Make sure there is no chips of sealing tape or other dusts getting into the water supply, air supply, fall prevention system, and ATC chuck/unchuck port. Otherwise, not only the product function and life may be adversely affected but also unexpected accident may occur.

---

**◆ MEMO**

- To install a robot adaptor, set the robot mounting surface facing up, rather than horizontal. Then robot adaptor installation becomes relatively safer.
- When installing a tool adaptor, set tools on the tool stand. Then tool adaptor installation becomes relatively safer.

---

**⚠ WARNING** Switch air supply to a chuck/unchuck port in the detached state to check that the coupling cam motions are correct. Operating without doing this may cause tool falling, product damage, or unexpected accident.

---

**⚠ DANGER** When manually switching air supply of the chuck/unchuck port, set tools on the tool stand. Otherwise, improper motions or piping may cause tool falling, product damage, or unexpected accident.

---

**⚠ CAUTION** Arrange cables and tubes without causing catching during robot motions. Otherwise, the ATC and its functional modules may be damaged.

---

#### e) Precautions for teaching

**⚠ WARNING** With the tool detached, check that the interlock signals output from the ATC are correct. Operating without doing this may cause tool falling, product damage, or unexpected accident.

---

**⚠ WARNING** For chuck/unchuck, switch air supply for chuck/unchuck with the coupling planes of robot side and tool side adaptors are horizontally coherent on the tool stand. Otherwise, an unexpected accident may occur due to tool falling, in addition to damage to the ATC and its functional modules due to prying.

---

**⚠ DANGER** When the welding power is on, there is a risk of electricity leakage. Do not touch any component connected with the ATC.

---

#### f) Precautions for Long-Term Shutdown or Transportation

**⚠ DANGER** The failsafe mechanism serves to prevent falling. Do not continue using the product when the air pressure is decreased. Otherwise, the gap between contact surfaces of robot and tool adaptor is increased and unexpected accident may occur. When the tool is left coupled by the failsafe mechanism only for a prolonged period of time, the gap between contact surfaces of robot and tool adaptor is increased by vibration, etc. and unexpected accident such as falling may occur. If it is absolutely necessary to stop the air supply for a long time with the tool coupled, be sure to take measures against falling, e.g. fixing it by rope, etc.

---

#### g) Precautions for disposal

When disposing of this product, please comply with laws and regulations.



# 1.Overview of the Automatic Tool Changer (ATC)

A pneumatic-driven system is employed for the Nitta ATC. Basically, the ATC consists of 2 components: a robot adaptor and a tool adaptor.

The ATC is compatible with all the robot tools with respective adaptor plates (optional). In addition, the ATC and its functional modules are equipped with transmission mechanisms such as a signal pin to transmit signals and power source to the tool, and pneumatic port.

## [ Transmission Mechanism ]

The ATC has an electric signal pin to transmit/receive signals between the robot and tool. For the number of pins, refer to the drawing.

## 1 - 1 . Robot Side

### 1 - 1 - 1 . Robot Adaptor

The robot adaptor is a basic component of the ATC. Each robot adaptor is equipped with sensors that transmit signals (chuck end signal, unchuck end signal and coupling check end signal) to communicate its attachment conditions.

## [ Chuck/Unchuck Mechanism ]

The cam mechanism to connect a robot adaptor and tool adaptor together is of a special structure, which is designed to automatically compensate for misalignment at the time of jointing and wear allowance to be generated over time. These cams are operated by an air cylinder and designed not to come off under temporary loading above the rated load.

Under such load, the contact surfaces of the robot adaptor and the tool adaptor will be slightly separated, but the adaptors will never be completely separated. Also, these cams are driven by a spring-return pneumatic cylinder, as a fail-safe mechanism to prevent falling of the tool adaptor even in the event of sharp reduction of the air pressure.

## WARNING

The failsafe mechanism serves to prevent falling. Do not continue using the product when the air pressure is decreased. Otherwise, the gap between contact surfaces of robot and tool adaptor is increased and unexpected accident may occur.

When the tool is left coupled by the failsafe mechanism only for a prolonged period of time, the gap between contact surfaces of robot and tool adaptor is increased by vibration, etc. and unexpected accident such as falling may occur.

If it is absolutely necessary to stop the air supply for a long time with the tool coupled, be sure to take measures against falling, e.g. fixing it by rope, etc.

## [ Chuck/Unchuck Sensor Signals ]

### ● Chuck end signal (coupling end)

Signal that indicates the cam is not fully engaged. When this signal and a coupling check signal are both active, the robot can pick the tool adaptor from the tool stand.

### ● Unchuck end signal (detachment end)

This signal indicates that a cam to lock (couple) the robot adaptor and tool adaptor is drawn into the robot adaptor. While this signal is active, the robot adaptor may approach the tool adaptor freely and leave the tool adaptor after completion of tool replacement on the tool stand safely.

### ● Coupling check end signal (face end)

This signal indicates that jointing planes of both the robot adaptor and tool adaptor are in contact.

When coupling the adaptors, make the coupling planes of the adaptors parallel and check that the coupling planes are sufficiently close to each other. Then operate the cam for coupling.

## 1-1-2. Selection of Input Device

**⚠ CAUTION** Check specifications of the input device. Signals representing the robot adaptor attachment condition may not be present.


The chuck/unchuck sensor signal output circuit of the unit consists of a photo coupler operated by turning the proximity sensor ON/OFF, and serial resistor for photo coupler protection. Therefore, the residual voltage of the signal output circuit varies depending on the input current of the selected input device.

For input device selection, check the input current of the device and ON determination voltage and select an input device with which ON determination is possible.

Example of [NPN: 0V common spec]: When input current value is 6 (mA)


- When chuck, unchuck are ON

$$\text{Residual voltage } V1 = 680 (\Omega) \times 6 (\text{mA}) + 0.9 + 0.8 = 5.78 (\text{V})$$



- When the coupling check end is ON

$$\text{Residual voltage } V2 = 680 (\Omega) \times 6 (\text{mA}) + 1.8 + 0.8 = 7.58 (\text{V})$$



Therefore, select an input device with which ON determination is possible with 8 (V) or higher voltage relative to 0V common.

### 1 -1 -3. Robot adaptor plate (optional)

Conforming to the ISO flange (P.C.D.200 (M12×6)) pattern, the adaptor is mountable to a robot flange.

They can also be mounted to various robots not compatible with the P.C.D.200 (M12×6) pattern with a robot adaptor plate.

No drilling and threading for mounting to a robot are performed on the standard robot adaptor plate.

(We may perform such processing upon your request. You may also prepare a robot adaptor plate on your own. When attaching the adapter plate to the robot adapter, see "5.Procedures of Installation to Robot/Tool".)

## 1 -2. Tool Side

### 1 -2 -1. Tool Adaptor

A tool adaptor is another fundamental component of the ATC, to which a tool is attached.

A tool adaptor is equipped with lock parts to be engaged with robot adaptor's locking cams.

### 1 -2 -2. Tool Adaptor Plate (Optional)

Conforming to the ISO flange (P.C.D.200 (M12×6)) pattern, the adaptor is mountable to a tool flange.

They can also be mounted to various tools not compatible with the P.C.D.200 (M12×6) pattern with a tool adaptor plate.

No drilling and threading for mounting to a tool are performed on the standard tool adaptor plate.

(As with the robot adaptor plate, we can offer a mounting hole drilling service following your instructions. You may also prepare an adaptor plate on your own. For precautions for installation of an adaptor plate onto the tool adaptor unit, please contact us.)

## 1 -3. Option

For details of options, e.g. non-standard signal pin modules, spot welding modules, and pneumatic modules, please feel free to contact us

## 2. Configuration:

This system is composed of the ATC (Robot Adaptor and Tool Adaptor) and additional functional modules assembled thereto.

The signal pin ASSY is a spring-type electric contact.




Fig. 1. System diagram

### 3. Standard Specifications


#### 3-1. Common Specifications

○Use conditions	
Ambient temperature	0-60°C (no condensation)
Ambient humidity	95%RH or below (no condensation)
Ambient atmosphere	Free of corrosive gas
Altitude	1000m or less
Vibration resistance	10-500 (Hz) Acceleration: 50 (m/s <sup>2</sup> ) for 110 minutes (compliant with IEC60068-2-6)
○Transport conditions	
Ambient temperature	-25-60°C (maximum instantaneous temperature: 70°C)
Ambient humidity	95%RH or below (no condensation)


## 3-2. ATC

## 3-2-1. ATC Specifications

Model	Robot Adaptor		See the drawing
	Tool Adaptor		See the drawing
Payload			350~600kg
Allowable moment			4000Nm
Allowable torque			4000Nm
Working pressure			0.39-0.85MPa
Position reproducibility			±0.025mm
Interface	Electricity	Number of electric contacts	See the drawing
		Rated voltage	50VDC or below
		Max. allowed current	3A
		Overvoltage category	Overvoltage category III
		Allowable pollution level	Pollution level 3
Weight	Robot Adaptor		9.77kg
	Tool Adaptor		7.94kg
Body material			Aluminum alloy
Dimensions	Robot Adaptor		See below
	Tool Adaptor		See below



R side adaptor  
(Refer to the delivery specifications and drawing for details.)



T side adaptor  
(Refer to the delivery specifications and drawing for details.)

**Note:** Refer to the delivery specifications and drawing.

**3-2-2. Internal Power Wire for ATC**

Name		Polyester flex-resistant power wire
Model		DKHV
Nominal sectional area		0.5mm <sup>2</sup>
Conductor	Material	Annealed copper wire for electricity
	Configuration: No. of wires/wire dia.	6/18/0.08 wires/mm
	Outer diameter	1.1mm
Insulation material	Material	Heat-resistant vinyl
Withstand voltage	Under water	2000V/5 min

Name		Polyester flex-resistant power wire
Model		DKXV
Conductor	Material	Annealed copper wire for electricity
	Configuration: No. of wires/wire dia.	6/11/0.08 wires/mm
	Outer diameter	0.9mm
Insulation material	Material	Flame-retardant polyester
Withstand voltage	Under water	1000V/min
	Sparking	5000V/0.15 sec.

**3-2-3. Coupling Check End Sensor**

Name	Anti-spatter proximity switch
Type	DC 2-wire shield type
Detection method	High-frequency oscillation
Rated power supply voltage	12/24VDC (common)
Operating voltage range	10-30VDC
Leak current	0.55mA or below
Operation mode	Normal open *1
Output mode	DC 2-wire; transistor output
Control output	Switching current: 3-100mA, Residual voltage: 3.0V or below Output withstand voltage: 30VDC
Response frequency	1500Hz or above

\*1: In proximity of detection object; load "operating"

**3-2-4. Chuck and Unchuck Sensor**

Name	Proximity switch
Type	DC 2-wire type or DC 3-wire type
Detection method	High-frequency oscillation
Rated power supply voltage	12/24VDC (common)
Operating voltage range	10-30VDC
Leak current	0.6mA or below
Operation mode	Normal open *1
Output mode	DC 2-wire or DC 3-wire type transistor output
Control output	Switching current: 3-50mA, Residual voltage: 3.0V or below Output withstand voltage: 30VDC
Response frequency	900Hz or above

\*1: In proximity of detection object; load "operating"

**3-2-5. LED ASSY Specifications**

This section describes specifications of photo couplers used in the LED ASSY equipped on the robot adaptor. For details, please refer to the specifications, etc.

Model	TLP187 (Toshiba)
Type	Red LED + Photodarlington transistor
Dielectric voltage	3750Vrms (minimum)
Collector-emitter breakdown voltage	300V (minimum)
Conversion efficiency	1000% (minimum) (IF=1mA)
Collector-emitter saturation voltage	1.0V (maximum) (IC=50mA)
High temperature dark current	20 $\mu$ A (maximum) (Ta=85°C)
UL-certified	UL1577 (File No.E67349)



## 3-2-6. Precautions for Allowable Load and Installation

**⚠ WARNING**

Rated load, rated moment, and rated torque in the ATC specifications are dynamic specifications for the unit being mounted on a robot. Ensure that the maximum load never exceeds these values during normal operations taking into account the acceleration factor during acceleration/deceleration by the robot. Fig. 2 shows the meanings of rated load, rated moment and rated torque.

Payload  $W = 3430\text{-}5880\text{N}$  (350-600kg)

Eccentric distance  $L = \sqrt{(lm^2 + lt^2)}$

Ex: Allowable bending moment  $M = L \times W \times G_R^{(*)} = 0.5 \times 4600 \times 1.5 \leq 4000\text{Nm}$

Allowable twisting torque  $T = L_t \times W \times G_R^{(*)} = 0.5 \times 4600 \times 1.5 \leq 4000\text{Nm}$

Note:  $G_R^{(*)}$  is the acceleration factor of constant acceleration/deceleration in automatic robot operations. For specific values of robot performance, please contact the robot manufacturer for further consideration. (Use 1.5-2.0G as a standard.)




Fig. 2. An example of rated load definition ( $G_R=1.5/2.0$ )

## 3-2-7. Allowable Electric Load


**⚠ CAUTION**

The ATC with the standard signal pin ASSY (20-pin), as an entire contact ASSY, is capable of carrying up to 13A current. Also, each of the pins is capable of carrying 3A current. However, when multiple signal pins are to be used, do not let 3A current be applied to any adjacent pin as it will cause insufficient insulation, leading to short circuit.

### 3-3. Spot Welding Module (Seal Connector Specifications)

#### 3-3-1. Spot Welding Module Specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.6kg
	Tool Side	0.6kg
Body material		Voltage-proof resin
Number of electrodes		Welding power 2 pieces, Ground 1 piece, Signal 2 pieces (max)
Rated voltage		Single-phase 600VAC
Max. allowed current		130A
Rated frequency		1000Hz
Overvoltage category		Overvoltage category III
Allowable pollution level		Pollution level 3



**3-3-2. Power Wire for Spot Welding Module (Power)**

Name			Electric wires for internal wiring and for power supply
Nominal sectional area			4AWG (21.1mm <sup>2</sup> )
Conductor (AC)	Material		Soft-copper stranded wire
	Configuration: No. of wires/wire dia.		7/126/0.18 wires/mm
	Outer diameter		6.9mm
Insulation material	Material		Heat-resistant flexible vinyl
Withstand voltage (under water)			2000V/min
Allowable current (30°C)	Usage (%)	100	130A


**3-3-3. Internal Power Wire for Spot Welding Module (Earth)**

Name			Electric wires for internal wiring and for power supply
Nominal sectional area			6AWG (13.3mm <sup>2</sup> )
Conductor (AC)	Material		Soft-copper stranded wire
	Configuration: No. of wires/wire dia.		7/84/0.18 wires/mm
	Outer diameter		5.7mm
Insulation material	Material		Heat-resistant flexible vinyl
Withstand voltage (under water)			2000V/min
Allowable current (30°C)	Usage (%)	100	100A



## 3-4. Spot Welding Module (Direct Cabling Specifications)

## Specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.6kg
	Tool Side	0.6kg
Body material		Voltage-proof resin
Number of electrodes		Welding power 2 pieces, Ground 1 piece, Signal 2 pieces (max)
Rated voltage		Single-phase 600VAC
Max. allowed current		200A ※Depending on cable specifications
Rated frequency		1000Hz
Overvoltage category		Overvoltage category III
Allowable pollution level		Pollution level 3



R side spot welding module




T side spot welding module

### 3-5. Servo Motor Module

#### 3-5-1. Servo Motor Module Specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.8kg
	Tool Side	0.9kg
Body material		Aluminum alloy
Number of electrodes	Motor power	6 electrodes
	Signal	15 electrodes
Rated voltage	Motor power	200VAC
	Signal	50VDC or below
Max. allowed current	Motor power	20A
	Signal	3A
Overvoltage category		Overvoltage category III
Allowable pollution level		Pollution level 3



## 3-5-2. Internal Power Wire for Servo Motor Module


Motor power			
Application		Brake	Power
Name		Polyvinyl chloride wire for electric appliances	
Model		KIV	
Nominal sectional area		0.75mm <sup>2</sup>	3.5mm <sup>2</sup>
Conductor	Material	Tinned annealed copper wire	
	Configuration: no. of wires/wire dia.	30/0.18 wires/mm	45/0.32 wires/mm

Signal		
Name		Large-diameter multipair cable
Model		UL2464-SB
Nominal sectional area		24AWG
Conductor	Material	Tinned soft-copper stranded wire
	Configuration: no. of wires/wire dia.	7/0.203 wires/mm
Insulation material	Material	Lead-free heat-resistant PVC
Final diameter		About 7.5mm
Withstand voltage		2000VAC/5 min


### 3-6. Hydraulic Module

#### Specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.93(kg)
	Tool Side	0.83(kg)
Body material		Stainless steel
Number of ports		4
Fluid used		Water (Available air)
Fluid temperature		0-80°C (no condensation)
Ambient temperature		0-60°C
Ambient humidity		95%RH or less
Normal pressure		0.86MPa
Cv value		3.3/PORT
Connecting screw size		Rc1/2



R side hydraulic module  
(Refer to the delivery specifications and drawing for details.)



T side hydraulic module  
(Refer to the delivery specifications and drawing for details.)

#### Recommended grease


Module parts No. (※1))	Grease type
CTRH** - 0**	Silicone grease SH44M (manufactured by Dow Corning Toray Co., Ltd)
CTRH** - NS*	
CTRH** - N0*	Mineral lithium composite grease SUMIPLEX BN NO.1(manufactured by Sumico Lubricant)

※1 : Select recommended grease for module parts No.


### 3-7. Pneumatic Module

#### 3-7-1. 4 Ports type specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.57(kg)
	Tool Side	0.60(kg)
Body material		Aluminum alloy
Number of ports		4
Fluid used		Air
Fluid temperature		0-80°C (no condensation)
Ambient temperature		0-60°C
Ambient humidity		95%RH or less
Normal pressure		0.86MPa
Effective sectional area		19.0mm <sup>2</sup> /PORT
Cv value		0.72/PORT
Connecting screw size		Rc1/4



R side Pneumatic module  
(Refer to the delivery specifications and drawing for details.)




T side Pneumatic module  
(Refer to the delivery specifications and drawing for details.)




3-7-2. 8 Ports type specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	1.03(kg)
	Tool Side	1.10(kg)
Body material		Aluminum alloy
Number of ports		8
Fluid used		Air
Fluid temperature		0-80°C (no condensation)
Ambient temperature		0-60°C
Ambient humidity		95%RH or less
Normal pressure		0.86MPa
Effective sectional area		19.0mm <sup>2</sup> /PORT
Cv value		0.72/PORT
Connecting screw size		Rc1/4



R side Pneumatic module  
(Refer to the delivery specifications and drawing for details.)




T side Pneumatic module  
(Refer to the delivery specifications and drawing for details.)

### 3-8. Signal module



Specifications

Model	Robot Side	See the drawing
	Tool Side	See the drawing
Weight	Robot Side	0.9(kg)
	Tool Side	0.9(kg)
Body material		Voltage-proof resin
Number of electrodes		35
Rated voltage		50VDC or below
Max. allowed current		3A
Overvoltage category		Overvoltage category III
Allowable pollution level		Pollution level 3



### 3-9. Fall Prevention System Specifications

Product No.	CAR-006-M*	
External dimensions (height x width x thickness)	60.4 x 80 x 62.3mm	
Main unit material	Aluminum alloy	
Weight	0.52kg	
Flow characteristics	C [dm <sup>3</sup> (s·bar)]	0.6
	b	0.15
Fluid used	Air	
Working pressure	0-1.0MPa	
Ambient temperature and working air temperature	0-60°C (no freezing)	
Joint diameter (nominal)	Rc1/4	
Grease up	Not required	



(Refer to the delivery specifications for details.)

## 4.Part Names




Fig. 3. Part names

## 5.Procedures of Installation to Robot/Tool

---

**⚠ DANGER** For use of ATC, be sure to observe safety instructions concerning core robots and compatible units. For any work within the robot safety fence, consider preparing a safety system design to shut down power over 50V once any person gets into the fenced area.

---

**⚠ WARNING** In addition, for works in the safety fence area, be sure to wear appropriate clothing for the work with personal protective equipment such as a hard hat, safety boots, etc. For internal disassembly works for the ATC, use protective glasses for protection against pop-out parts.

---

**⚠ CAUTION** Personnel engaged in installation, programming and maintenance works inside the robot safety fence for the ATC must have expertise in robot operations (having completed expert training). In addition, those engaged in disassembly or assembly works of the ATC, whether in or out of the safety fences, shall read this document and the maintenance procedures.

---

### 5-1. Robot Adaptor

The robot adaptor can be mounted to a robot compatible with the ISO flange pattern.  
(P.C.D.200 (M12 x6)) (Refer to Fig. 1.)

Mounting bolt ASSY: M12 6 pcs. [Torque: 80Nm]

(\*Used with M12 disc spring washers, insulation washers and insulation collars)

Dowel pins (customer-supplied or option parts)

Refer to the delivery specifications and drawing for details.

To use the robot adaptor plate (optional), drill the plate to make appropriate mounting holes (or threads) for the robot. Mount the robot adaptor plate to the robot first and then mount the robot adaptor on it.

---

**⚠ WARNING** When manufacturing (processing) a robot adaptor plate at your company, do not drill holes over  $\phi 125\text{mm}$  in the center of the robot adaptor plate for the purpose of light weight etc.  
Otherwise, the robot adaptor may be damaged and the chuck/unchuck operation may not be possible.

---

### 5-2. Tool Adaptor

The tool adaptor can be directly mounted to a tool compatible with the ISO flange pattern.  
(P.C.D.200 (M12x6)) (Refer to Fig. 1)

Mounting bolt ASSY: M12 6 pcs. [Torque: 80Nm]

(\*Used with M12 disc spring washers )

Dowel pins (customer-supplied or option parts)

Refer to the delivery specifications and drawing for details.


To use the tool adaptor plate (optional), drill the plate to make mounting holes or threads appropriate for the tool, and then mount the tool adaptor

- ⚠ CAUTION** If you manufacture (process) a robot/tool adaptor plate on your own, be sure to ensure sufficient depth of counterbore so that the head of any mounting screw will not protrude from the mounting surface of each adaptor plate.
- When using male screws from the tool side to attach a tool to a tool adaptor, adjust the bolt length so that the tip of any male screw will not protrude from the tool adaptor plate surface.


- ⚠ CAUTION** Be sure to use locking agent (low strength) for mounting bolts when tightening them.

Tighten bolts in the order of the numbers in steps so that equal force is applied to each bolt.  
E.g. Tightening screws in a criss-cross pattern starting with (1), (2), (3) and so on.

**⚠ CAUTION**



For the installation work, set the robot flange surface facing upward at the height of your breast to prevent ATC from falling.



Bolt tightening sequence and precaution

- ⚠ CAUTION** Tightening bolts with torque above the specified torque level may damage screw threads on the robot side or tool side and ATC itself.
- Further, tightening bolts with torque below the specified torque level or failure to use the locking agent may cause bolts to be loosened, leading to ATC fall off.


### 5-3. Connecting to Fitting/Removal Port

Connect piping from the solenoid valve to the "CHUCK" port and "UNCHUCK" port of the fitting/removal mechanism. The constant pressure line (with the valve not energized) must always be connected with the "CHUCK" port to maintain coupling of the chuck/unchuck port in the event of power failure.


#### ⚠ WARNING

Be sure to shut off the power supply, air, water and hydraulic power before starting the work.

- Be careful to ensure tubes are connected to right ports (chuck port (CH) and unchuck (UN) port). Otherwise the tool may fall off.
- Clearly mark the chuck (CH) and unchuck (UN) tubes accordingly.
- Securely insert the tubes to the end to prevent accidental disconnection.
- There are two types of chuck/unchuck air piping: standard spec and solenoid valve spec (a robot adaptor with solenoid valve).
- For the solenoid valve spec, there are one air supply port.
- Do not manually switch the air supply without an absolute need to do so.



Standard



Solenoid valve spec

Single tube connection for solenoid valve spec

#### ⚠ WARNING

Leave the "UNCHUCK" port opened without plugging even when chuck/unchuck is not to be performed (in a coupled state only). Also, be sure to pressurize the "CHUCK" port when using it. Otherwise, it may fall off.

#### ⚠ DANGER

About air piping for ATC driving:

ATC has a fail-safe mechanism to prevent the tool side from falling even when air pressure is unexpectedly decreased. However, the air piping for ATC driving requires proper selection and arrangement of solenoid valve to prevent air from flowing into the "unchuck" side even when the valve is electrically turned OFF.


- Do not use any three-position, closed-center type solenoid valve. The chucked state cannot be maintained with the power supply turned OFF, which may result in falling.
- Do not share an exhaust port with other equipment. Otherwise, the chucked state cannot be maintained due to wrap-around back pressure, which may result in falling.
- Do not branch the air supply to the "CHUCK" port to other equipment. Otherwise, the chucked state cannot be maintained due to reduced pressure, which may result in falling.

**⚠ CAUTION**

Do not perform chuck / unchuck operation before installing it to the robot. Make sure robot adaptor must be fixed with bolts to the robot when it will be chucked / unchucked. Otherwise, the blank plate on the mounting surface may be damaged and inoperable.

**⚠ WARNING**


Perform installation carefully not to bend the tube connected with the chuck/unchuck port during robot motions. Otherwise, it may fall off.



- Tube bending
- Tube twisting
- Excessive tightening of tube with banding band

**⚠ WARNING**

Do not cap the exhaust port of the solenoid valve used for switching pressure on the chuck/unchuck port. Otherwise, it may fall off.

**⚠ CAUTION**

As a solenoid valve used for switching pressure on the chuck/unchuck port, select a double-solenoid type valve. Then effects of any noise malfunction are mitigated.

**⚠ WARNING**

Make sure there is no chips of sealing tape or other dusts getting into the ATC chuck/unchuck port. Otherwise, not only the product functionality and life may be adversely affected but also unexpected accident may occur.




## 5-4. Electric Wiring

With reference to the internal wiring chart, connect the input and output wires to robot adaptor terminals (connectors). Connect the built-in sensors to a robot (line, etc.) control system.

Signals from these sensors will be taken through the aforementioned terminals. In case of the connector spec, be sure to securely insert the connectors.

**⚠ WARNING** Perform wiring as per the delivery specifications. Improper wiring may cause failure or electric leakage, etc.

**⚠ WARNING** Securely apply Class III grounding for earth and shield lines. Otherwise, electric shock and noise may occur, leading any malfunctions.




Securely and fully tighten to prevent connector disconnection during robot operations.

**Fig. 4.** Connection of cable connector

## 5-5. Cable Fixing

**⚠ CAUTION** Robot side cables must be securely tied together with other cables and tubes and fixed around the robot adaptor's connector part by using a spiral tube or banding band, etc. Also ensure that cables and tubes are free of any excessive force while the robot's wrist axis is rotating. Excessive force applied onto cables and tubes may break a connector of the joint part and an electric module, etc. or cause open-circuit. It may also cause any electric shock hazard and sparking. An example of cable fixing by a bracket is shown in Fig. 5

### Reference




**Fig. 5.** An example of cable fixing

## 5-6. ATC Grease up

Pressure-, heat-, and water-resistant mineral lithium composite grease or lithium grease should be applied thinly and evenly to external sliding faces. Application points are indicated in **Fig. 6**. For new products, please check that grease has been already applied in plant.  
(Recommended grease: SUMIPLEX BN NO. 1 (manufactured by Sumico Lubricant))

**⚠ CAUTION** Do not use molybdenum grease. As Nitta uses mineral lithium composite grease, be sure to use the same type of grease. Recommended NLGI No. (JIS consistency number) is No.1 and No.2.



**Fig. 6. ATC greasing points**


**⚠ CAUTION** Without greasing, prying and early wear will be generated on each part.

## 5-7. Precautions for Installing ATC to a Tool

### 5-7-1. ATC Orientation

**MEMO** In order to minimize the gap between mating surfaces, it is recommended to install ATC so that the maximum possible load is oriented as illustrated in the figure below.

#### **Referenc**



**Fig. 7.** ATC orientation

### 5-7-2. Precautions for using a servo motor for a tool

**MEMO** If you use a tool with a servo motor (servo gun/servo material handling equipment, etc.), install a battery for memory storage on the tool side or use an encoder with no need for powered memory storage in preparation for power failure to the encoder for separation. In addition, functionality to electrically disconnect/connect the servo motor is necessary on the robot.

## 5-8. Procedure for Installing Module to ATC

### 5-8-1. Module Mounting Bolts

Chart 1. Module assembly bolts and torque level \*1

		R side	T side	
		Spot Welding	Screw shape	M5×30 SUS + Spring water + Flat washer
	Nitta model No.	GSSH05030S + GWSP05S + GWFH0510		
	Torque	5Nm		
Servo Motor		R side	T side	
		Screw shape	M5×30 SUS	
		Nitta model No.	GSSH05030S	
		Torque	5Nm	
Hydraulic		R side	T side	
		Screw shape	M5×15 SUS	
		Nitta model No.	GSSH05015SM *2	
		Torque	5Nm	
Pneumatic		R side	T side	
		Screw shape	M5×35 SUS	
		Nitta model No.	GSSH05035SM *2	
		Torque	5Nm	
Signal		R side	T side	
		Screw shape	M5×30 SUS + Spring water + Flat washer	
		Nitta model No.	GSSH05030S + GWSP05S + GWFH0510	
		Torque	5Nm	
Fall Prevention System		R side	T side	
		Screw shape	M5×30 SUS	M5×10 SCM
		Nitta model No.	GSSH05030S	GSSH05010M
		Torque	5Nm	5Nm

\*1 Apply screw locking agent (low strength) to each bolt.

\*2 Locking agent application is not needed for the supplied bolts, to which locking agent is already applied (green mec; low strength).

**⚠ CAUTION** Tightening bolts with torque above the specified torque level may damage threads on the ATC side and modules.  
Further, tightening bolts with torque below the specified torque level or failure to use the locking agent may cause bolts to be loosened, leading to module fall off.

## 5-8-2. Wiring for Spot Welding Module of Direct Cabling Specifications

**⚠ WARNING** Perform wiring as per the delivery specification drawings. Improper wiring may cause failure or electric leakage, etc.

**⚠ WARNING** Securely apply Class III grounding for earth and shield lines. Otherwise, electric shock and noise may occur, leading any malfunctions.

## 1) Crimp terminal selection

Use cables of compatible cable O.D. specified in your facility specifications or relevant module drawings.


**Chart 2. Possible crimp terminals and compatible cable diameters**

Crimp terminal model (Nitta part no.)	Compatible cable dia.	
	(mm <sup>2</sup> ) (SQ)	AWG
GLUGR38-6S	26.66-42.42	2
GLUGR22-6S	16.78-26.66	4
GLUGR14-6S	10.52-16.78	6

**⚠ WARNING** Wrong positioning of the earth may cause electric shock or device damage. For wiring arrangement, follow the module drawing.

## 2) Cabling

(1) Let a cable through the interface housing.



**Fig. 8. Spot welding cable assembly**

**⚠ CAUTION** Use rubber bush of an appropriate size for the cable diameter. Otherwise, water drops or dust may come into the housing and cause malfunctions, e.g. electrode damage and poor conduction.

**Chart 3. Spot welding cable diameters and compatible rubber bush**

Cable dia.	φ14.4-15.9	φ11.2-14.3	φ8-11.1
Compatible rubber bush	AN3420-12	AN3420-12 + AN3420-10	AN3420-12 + AN3420-10 + AN3420-8

- (2) Peel the cable coating for 10mm length from the tip.




Fig. 9. Cable coating peeling

- (3) Fit a crimp terminal suited for the cable diameter and use a hydraulic crimping tool to tighten the crimp terminal further.




Fig. 10. Crimp terminal tightening

### 3) Cabling

#### **⚠ WARNING**

Wrong positioning of the earth may cause electric shock or device damage.  
For wiring arrangement, follow the module drawing.

- (1) Make sure you set the crimp terminal with the right side up, tighten the brass screws (M5 x 8) with a cross-tip torque wrench and mark the position. [Torque level: 3.5Nm]






Fig. 11. Crimp terminal fixing

(2) Fix the cable with the clamp. (Cross-slot screws) [Torque level: 1.5Nm]




**Fig. 12. Cable fixing by cable clamp**

(3) Let the signal cable through the cable gland and adjust the length with reference to the power supply cable. Then cut the cable 50mm from the housing.



**Fig. 13. Signal cable length arrangement**

(4) Peel the coating 6mm from the tip and crimp the crimp terminal.



**Fig. 14. Signal cable crimping**

- (5) Connect the crimp terminal of the signal cable and put into the housing.  
Fix the cable ground. [Torque level: 0.4Nm]




Fig. 15. Signal cable crimp terminal connection and housing


**⚠ CAUTION**

After fitting the spot welding module to the adaptor, fix cables at appropriate position for robot motions to prevent cables from being pulled by robot motions.

Tension on the cables may cause connector breakage and electrode failure, resulting in sparking.

**⚠ WARNING**

•Precautions for cable connection in case of seal connector spec  
An electrode on a robot side power module can move up and down by approx. 1.4mm. If the cable is pulled during robot operations, the electrode may not work properly resulting in improper power supply and burnout.






**⚠ CAUTION**

Robot side cables must be securely tied together with other cables and tubes and fixed around the robot adaptor's connector part by using a spiral tube or banding band, etc. Also ensure that cables and tubes are free of any excessive force while the robot's wrist axis is rotating. Excessive force applied onto cables and tubes may break a connector of the joint part and an electric module, etc. or cause open-circuit. It may also cause any electric shock hazard and sparking.

An example of cable fixing by a bracket is shown in lower illustration.

**📖 Referenc**

**Fig. 16. Example of cable fixing**

### 5-8-3. When a Servo Motor Module is used:

**⚠ WARNING**

Perform wiring as per the delivery specification drawings. Improper wiring may cause failure or electric leakage, etc.

**⚠ WARNING**

Securely apply Class III grounding for earth and shield lines. Otherwise, electric shock and noise may occur, leading any malfunctions.

## 5-8-4. When a hydraulic module is used:

- ⚠ CAUTION** Ensure no chips of sealing tape, etc. get into the module. Otherwise, it gets into the O-ring sealing section inside and causes leakage.
- 
- ⚠ CAUTION** Please use recommended grease or equivalent items on the liquid port surface.  
If unproper grease would be used, O-rings will swell and cannot be used.  
In the case of non-lubrication, early breakage and leakage may occur.
- 
- ⚠ CAUTION** In case of a silicone grease in the chart below, the grease used for the robot/tool adaptors must not be used. Please use our specified grease, silicone grease SH44M (manufactured by Dow Corning Toray Co., Ltd).  
Equivalent items are silicone oil-based grease of NLGI No. (JIS consistency number) 1 and 2.
- 


**Hydraulic/coolant ASSY greasing**

Use Nitta's recommended grease or an equivalent item for hydraulic/coolant ASSY greasing, which should be thinly and evenly applied onto the robot side O-ring. Application points are indicated in Fig. 17.

**Chart 4. Recommended grease**

Module parts No. (※1)	Grease type
CTRH** - 0**	Silicone grease SH44M (manufactured by Dow Corning Toray Co., Ltd)
CTRH** - NS*	
CTRH** - N0*	Mineral lithium composite grease SUMIPLEX BN NO.1(manufactured by Sumico Lubricant)

※1 : Select recommended grease for module parts No.

**Fig. 17. Greasing points on hydraulic/coolant port ASSY (Robot side)**

- ◆ MEMO** If you take measures for water quality management, i.e. using a filter for coolant, chance of pollution and foreign substance intrusion in the module is reduced.

**5-8-5. When a pneumatic module is used:**

**⚠ CAUTION** Ensure no chips of sealing tape, etc. get into the module. Otherwise, it gets into the O-ring sealing section inside and causes leakage.

**⚠ CAUTION** Mineral oil grease (Sumiplex BN No.1 Sumiko Lubricant Co., Ltd.) is applied to the O-ring of the module.  
When greased, use the same type of grease.  
If non-compliant grease is used or if it is not lubricated, early breakage and leakage may occur.

**5-8-6. When a Signal Module is used:**

**⚠ WARNING** Perform wiring as per the delivery specification drawings. Improper wiring may cause failure or electric leakage, etc.


**⚠ WARNING** Securely apply Class III grounding for earth and shield lines. Otherwise, electric shock and noise may occur, leading any malfunctions.

**5-8-7. When a Fall Prevention System Is Used:**

**⚠ CAUTION**

- Ensure that there is no problem with piping.
- Ensure that the lever and DOG positions are as per the delivery specifications.

**⚠ WARNING** Perform installation carefully not to bend the tube connected with the chuck/unchuck port during robot motions. Otherwise, it may fall off.



- Tube bending
- Tube twisting
- Excessive tightening of tube with banding band

**⚠ WARNING** Make sure there is no chips of sealing tape or other dusts getting into the fall prevention system chuck/unchuck port. Otherwise, not only the product functionality and life may be adversely affected but also unexpected accident may occur.

**⚠ WARNING** The fall prevention function may deteriorate due to the seal or other dusts entering the fall prevention mechanical valve or the deterioration of the internal seal, which may cause an unexpected accident.  
Please check the valve function regularly.

## 6.Operations and Programming

### 6-1. Checking before Teaching (Robot Operations)

**⚠ CAUTION** Ensure that cables and tubes (hereinafter cables, etc.) are routed and fixed to the bracket without breaking. Also, ensure that the cables, etc. are fixed so that they do not interfere with peripheral components and work pieces during robot operations. \*See 5-5. Cable Fixing.


**⚠ CAUTION** Ensure that grease is applied to the ATC for Robot side.  
※See 5-6. ATC Grease up.

**⚠ CAUTION** Ensure that grease is applied to the hydraulic/pneumatic module .  
※See 5-8-4. When a hydraulic module is used:

**⚠ WARNING**


- 1) Ensure that air supply is not shut off by bending/twisting of the unchuck tube and excessive tightening of the banding bands. When the air supply is inhibited, the cam may not work properly resulting in tool side module falling.
- 2) Check that the unchuck port air is discharged before coupling (no residual pressure). Any residual pressure may prevent normal cam operations and cause the tool side modules fall off.

1) Tube



- Tube bending
- Tube twisting
- Excessive tightening of tube with banding band

2) Solenoid



**⚠ WARNING** When operating a robot with a tool coupled, be sure to supply air to the chuck port.

## 6-2. Operations and Programming

This section describes a simple example of external interlock signals of the ATC. The ATC requires synchronization with a robot and peripheral devices and exchange of operation check signals to ensure reliability and safety.

The ATC has three built-in sensors for detection of its own motions. For details, please refer to "Overview of the Automatic Tool Changer (ATC)."

### **⚠ WARNING**


Configure interlock settings for chuck (\*1), unchuck(\*2), face (\*3) and tool presence signals, etc. of the ATC. Check that the cam opening/closing is properly detected by the three face sensors and the respective LED lamps (\*4) light up accordingly. Check that interlock signals are input to the superior control devices, such as PLC. Without setting of external interlock signals, safety may not be ensured in the event of operator errors or malfunction, posing a risk of tool falling.

\*1. Chuck signal: Indicates that cam is opened

\*2. Unchuck signal: Indicates that cam is closed

\*3. Face signal: Indicates that coupling planes of the robot adaptor and tool adaptor are closely mated together

\*4. LED lamps: Light up in different patterns to indicate the above signal output patterns



**Fig. 18. An example of interlock setting**

- The illustration above shows an example interlocking scheme for your reference. Please design safe interlocking scheme appropriate for your facilities.
- We offer specs with fall-protection mechanical valve or safety switch. (For details, please feel free to contact us.)
- If you do not choose to have our fall-protection mechanical valve or safety switch, be sure to introduce an appropriate safety system separately.

### 6-3. Basic Flow of ATC

Please check the flow outlined in Chart 5 below and ensure the robot interlocking.



Chart 5. Basic flow of ATC

Robot motion		Input			Robot Output		External input	LED Output		
		Chucking Sensor			Controlling		Fixture Limit	LED ASSY		
		Face	Chuck	Unchuk	Chuk	Unchuck	Tool side	Face	Chuck	Unchuk
CHUCKING	Waiting position	OFF	OFF	ON	OFF	ON	ON	OFF	OFF	ON
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Near by chucking position	↓	↓	↓	↓	↓	↓	↓	↓	↓
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Approaching	↓	↓	↓	↓	↓	↓	↓	↓	↓
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Chucking position	ON	↓	↓	↓	↓	↓	ON	↓	↓
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Chuck	↓	ON	OFF	ON	OFF	↓	↓	ON	OFF
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Chucking completion	↓	↓	↓	↓	↓	↓	↓	↓	↓	
↓	↓	↓	↓	↓	↓	OFF	↓	↓	↓	
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Working	↓	↓	↓	↓	↓	↓	↓	↓	↓	
UNCHUCKING	Working	ON	ON	OFF	ON	OFF	OFF	ON	ON	OFF
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Moving	↓	↓	↓	↓	↓	↓	↓	↓	↓
	↓	↓	↓	↓	↓	↓	ON	↓	↓	↓
	Unchuck position	↓	↓	↓	↓	↓	↓	↓	↓	↓
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Unchuck	↓	OFF	ON	OFF	ON	↓	↓	OFF	ON
	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
	Leaving	OFF	↓	↓	↓	↓	↓	OFF	↓	↓
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Near by unchucking position	↓	↓	↓	↓	↓	↓	↓	↓	↓	
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Moving	↓	↓	↓	↓	↓	↓	↓	↓	↓	
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Waiting	↓	↓	↓	↓	↓	↓	↓	↓	↓	

 represents process stepping conditions.

- "ATC coupling check end ON" should be active during robot operations (during production).

#### WARNING

Continuous signaling is recommended for solenoid valves for chuck/unchuck. Please do not use one-shot signaling because it may not maintain the chuck status due to malfunction caused by any noise resulting in module falling.

#### CAUTION

Please shut off the electric signals applied to the ATC signal pin before chucking and unchucking. If the signal pins are connected or disconnected while the signal is on, the surface of the signal pins might be damaged due to electric shock, etc., and the signal pins may deteriorate faster.

## 6-4. Interlocking around ATC

For safe and smooth operations of ATC, it is recommended to configure the following signals.

- 1) Signal of detection of decreased air pressure for ATC driving  
This signal notifies a robot of reduction of ATC driving air pressure for any reason, and robot operations will be halted when this signal is turned OFF.
- 2) Tool side presence signal  
This signal detects the tool side unit of ATC (material handling equipment, etc.) is on the tool stand. This is an interlock signal to provide unchuck valve ON output, check that the ATC is securely located on the tool stand, and proceed with next robot step while checking that the entire tool side unit of the ATC is on the tool stand. This prevents the tool from falling in any unexpected situation.

---

 **WARNING**

The tool presence signal is a very important interlock signal to tell the ATC can be detached safely.

Failure to use the tool presence signal as an interlock signal may cause the tool fall off during manual operations, leading to an unexpected accident.

---

- 3) Tool No. check signal  
This signal is used by the ATC to check consistency between a coupled tool and running program No. when, for example, multiple robots are coupled with a tool from the same tool stand.
- 4) ATC operation check signal indicators  
It is recommended to install indicators that constantly shows ON/OFF states of the aforementioned three signals (chuck end, unchuck end, and coupling check end signals) indicating the ATC operation status, and user signals used with the ATC (e.g. tool clamp end work presence).  
This allows to readily comprehend any signal-related trouble and interlock waiting status.

## 6-5. Precautions for Operations

**⚠ WARNING** Do not separate the robot adaptor carelessly when the tool adaptor is not in its home position on the tool stand.  
Separating the tool adaptor while not in its home position may damage ATC or peripheral equipment and/or hurt operators.

**⚠ CAUTION** Basically, the connection surfaces of the robot adaptor and tool adaptor must be in parallel during the ATC attaching/detaching operation. Otherwise, proper chuck and smooth unchuck may be prevented. Moreover, the electric contacts and hydraulic/pneumatic ports may be spoiled earlier. If it is not possible to maintain parallelism with the robot and the tool stand, the tool stand must have an alignment function. On a tool stand with an alignment function, mate the flat planes by pressing the robot adaptor against the tool adaptor for proper teaching. (The alignment function must be designed to compensate for robot thrust, tool weight, flatness, and center deviation.)

Also, in the unchuck process, the tool adaptor may lean and cause prying due to reaction force of ATC's electric contact and pneumatic port, preventing unchuck. In such cases, the robot adaptor must be pressed against the tool adaptor as in the coupling process to prevent the tool adaptor from moving (deviating and leaning) right after unchuck. At this point, the tool must remain on the tool stand. Then, perform teaching so that the built-in sensors can detect unchuck and ensure smooth evacuation without prying.

We have teaching jigs, so please feel free to contact us if you are interested.




Fig. 19. Precautions when teaching

**◆ MEMO** For the above, it is recommended to place ATC's tool stand on the level. However, if it needs to be upright due to a space constraint, please consider the following.

- 1) There must be no backlash of the tool adaptor's tool stand (besides the alignment function).
- 2) It must not move due to tool's offset load during unchuck or chuck of the tool adaptor. (As far as possible, it should be supported near the tool adaptor.)
- 3) It must be pressed with sufficient pressure for coupling with the tool adaptor and have sufficient rigidity to prevent deflection of the tool stand. Also the anchor bolts must not be loosened or come off.



- 4) Tool side supports and tool side supported positioning sections of the tool stand must be abrasion resistant. It is desirable that parts can be replaced.

---

◆ MEMO

If the ATC is applied for demurring or other machining, position the tool stand so that no cutting chips and cutting oil are adhered to the tool adaptor.  
If the stand position is exposed to adverse environment with spatters, water drops and dust particles, install an automatic cover or the like to protect the tool adaptor. Further, in oily atmosphere, ensure good conduction by, for example, air blow on the signal pin section.

---

We offer standardized peripheral devices for the ATC such as fall-prevention system. For details, please feel free to contact us.

## 6-6. Points to Check during Line Downtime (or Line Uptime)

### ⚠ WARNING

#### ● Recommended usage

During the robot downtime, e.g. nighttime or holidays, keep the tool side module detached.

During uptime, check that the cam is closed at the time of approaching for coupling of the tool side unit. Coupling operations performed with cam left opened may cause crash between the cam and lock parts, resulting in component damage.




Fig. 20. Precautions for Line Downtime

### ⚠ DANGER

#### ● Usage not recommended (only allowed if there is an absolute necessity)

If the tool side adaptor cannot be kept detached during downtime due to any reasons related to the facilities, take due care of the following.

If the line has to be stopped with the tool side module coupled, be sure to release the unchuck port regardless of air supply pressure presence.

(No residual pressure allowed.)

If the unchuck port is not released, the cam may be operated due to air wraparound resulting in tool side module falling. Position the tool appropriately to prevent falling and turn the power and air supply OFF before stopping the equipment.

There may be residual air pressure when: (see 6-1.)

- air supply is shut off by bending/twisting of the unchuck tube or excessive tightening of the banding bands; or

- the exhaust ports of the manifold and solenoid valve are plugged.

Points to check before restarting the line:

- Ensure there is no gap between the coupling planes.




Fig. 21. Positions that should be avoided during line downtime

## 6-7. Emergency Response Actions

### 6-7-1. Response Actions to Interference or Crash

**⚠ CAUTION** In the event of interference or crash with a robot or a jig attached to the robot (e.g. gun and transformer, etc.), be sure to take the inspection and response actions described in Chart 6. A significant force is applied to ATC upon interference or crash, which may create any factor that shortens the product service life. Therefore, the inspection interval may need to be shortened as necessary. For ATC replacement and damaged part replacement, please refer to relevant sections of this document and the "Maintenance Procedures."

**Chart 6. Response actions to interference or crash**

	Check item	Check method	Response action to abnormality
1	Presence/absence of cracking	Visual	ATC replacement
2	Housing deformation	Visual	ATC replacement
3	Loose bolts	Mounting bolts	Re-tightening
4	Cam chuck/unchuck operations and signal system check	Turn the valve ON/OFF manually and check operations and signal ON/OFF.	ATC replacement
5	Presence/absence of gap of coupling planes	Visual: Cam surface damage; lock parts and pivot pin breakage and damage; and mating surface dent	Replacement of damaged parts
6	Presence/absence of rattle in the rotation direction	Visual: Tapered pin breakage; bush damage; and loose bolts	Replacement of damaged parts
7	Check for damage in electric signal pins and connector cables, etc.	Visual, and I/O panel signal check	ATC replacement and replacement of damaged parts

### 6-7-2. Response Action to Water Exposure

**⚠ CAUTION** If the equipment is exposed with water, immediately stop using it and check if water enters into the product. Using the equipment with water presenting in internal electric component may cause signal output failure due to short-circuit. Moreover, when grease is washed out by water, sliding parts will be subject to higher friction, which can result in poor coupling or sealing. In the event of exposure to water, be sure to conduct the inspection and actions specified in Chart 7.


**Chart 7. Response actions to water exposure**

	Check item	Check method	Action
1	Electric contact and proximity SW signal	Check for short-circuit on the I/O unit side. Visually check for malfunction of the chuck/unchuck sensor and LED ASSY, and ensure there is no water infiltration.	If any, wipe off with a dry cloth. (*Do not attempt to blow water off with an air gun or the like as doing so may let water get further into the equipment.)
2	Cam, lock parts and tapered pin	Visual check	Apply grease
3	O-ring	Visual check	Apply grease
4	Other section exposed with water	Check all sections for water accumulation and wipe off if any.	Apply grease to uncoated metal parts.

### 6-7-3. Precautions for Transportation

**⚠ WARNING**

To move the system with the modules coupled together without air supply, use rope or the like to bind them and prevent tool side module from falling.



**Fig. 22. Precautions for transportation**

