


HEATING PRESS NPS-2005-1/2 OPERATOR'S MANUAL



- Thoroughly read this operator's manual before operating the press.
- To use endless splicing tools safely, be sure to hand this manual to the operator or worker.

NITTA CORPORATION

Table of Contents

1. Safety Precautions 2
2. Confirmation of Product 6
3. Specification 7
4. Operation Environment 8
5. Storage Environment 8
6. Name of each Parts 9
7. Operation Procedure 11
8. Endless Splicing Procedure 13
9. Troubleshooting 17
10. Inspection 18

1. Safety Precautions

We would like to thank you for having purchased our Integral Heating and Cooling Press **NPS-2005**

Thoroughly read this manual, especially the chapter on Safety Precautions, to use this machine safely.



This indicates a hazardous situation which, if improperly handled, will result in death or serious injury.



This indicates a potentially hazardous situation which, if improperly handled, will result in minor injury or property damage.

WARNING



Do not use this machine for any use other than belt endless splicing. Any use not intended for the prescribed purpose may invite an unexpected accident.

Improper use may render ineffective the safety protection features of the product.



This machine is not intended for use by the physically, sensory or mentally handicapped. They must have the supervision of a person responsible for their safety, if they use this machine.

Failure to do this may cause fire, electric shock or injury.



Do not allow children to handle this machine. Keep this machine out of reach of children.

Failure to do this may cause fire, electric shock or injury.



A person with technical knowledge and skills should always operate, WARNING maintain and inspect this machine.

> Handling by a person not having technical knowledge may cause fire, electric shock or injury.



Strictly avoid disassembling or remodeling this machine.

Disassembling or remodeling this machine may cause fire or electric shock. When repair or check is required, please contact your local distributor, agent in your area or our company.



In the event of trouble (smoke, fire or nasty smell, etc.), please immediately disconnect the power plug and contact your local distributor, agent in you area or our company for inspection or repair. Failure to do this may cause fire or electric shock.



When not using or carrying this machine, be sure to set the hook and turn the rotary handle until it slips to securely clamp the heat plate. Failure to do this may cause injury.



Confirm that the power supply to be used is within the designated of specification for this machine.

Failure to do this may cause fire or electric shock.

Model	Power supply		
NPS-2005-1	100 - 120V 50 / 60Hz		
NPS-2005-2	200 - 240V 50 / 60Hz		



Avoid using the press in the following environment.

WARNING Failure to do this may cause fire or electric shock.

- · In an atmosphere of inflammable or ignitable gas
- In an atmosphere of corrosive gas
- In ambient temperature of 5°C or below
- In ambient temperature of 40°C or above
- In an atmosphere of high humidity (environment where humidity exceeds 85%)
- In an environment subject to wet conditions from steam, water droplets or dew condensation, etc.



Be sure to wear heat-resistant gloves when operating this press.

Failure to do this may cause burns.



When operating this press, avoid touching the heat plate area even if wearing heat-resistant gloves.

Failure to do this may cause burns, even if wearing heat-resistant gloves, since press heat plates get heated to the press's preset temperature once the press is plugged in.



Avoid operating the press at the place close to combustible material.

Failure to do this may cause fire.



Always use the pre-setter designed for this product.

Failure to do this may cause fire or electric shock.

Use of a pre-setter made for other products or by another manufacturer may render ineffective the safety protection features of the product.



Use a dry cloth for cleaning this machine. Strictly avoid using alcohol, benzene, thinner or other inflammable solvents.

Using inflammable solvents may cause fire.



Impressed voltage is directly applied to the power cable. Observe the following precautions not to damage the cable.

Failure to do this may cause fire or electric shock.

- Disconnect the power plug by hand.
- Avoid pulling the cable to disconnect the power plug.
- Avoid modifying the power plug or replacing the plug with one from another manufacturer.
- Avoid placing anything on the power cable.
- Avoid bending the power cable.
- Take care to prevent the power cable from touching the heat plate of the press.



Connect the power plug to the socket correctly.

Failure to do this may cause electric shock.

The power cable of this machine uses a grounded connection plug. Connect the power plug correctly into a grounded connection socket.



Use a conversion plug when the plug shape does not match the socket.

Failure to do this may cause electric shock.

The plug shape of the attached power cable is as follows. The conversion plug is not attached. When a conversion plug is necessary, users must provide their own.

Model	Plug type	Plug illustration
NPS-2005-1	А Туре	
NPS-2005-2	CEE7 (S Type)	(°)



Never handle this machine or the plug, cable, etc. with wet hands. Failure to do this may cause electric shock..



Never use this machine if it is wet.


Failure to do this may cause electric shock or fire..

CAUTION




Exercise care not to pinch your hands between the top cover and control box or the upper and lower heat plates.

Failure to do this may cause injury.





Avoid inserting your hands into the opening on the front face of the press. Failure to do this may cause burns..





Avoid using this machine outdoors.

CAUTION This product is not intended for the use outdoors.



Avoid dropping this machine or giving it a strong jolt.

Failure to do this may cause fire or electric shock.



Take measures to prevent this machine from dropping or falling, and do not install or operate the press in an unstable location.

Failure to do this may cause injury, fire or electric shock.



Carry out the inspection described on page 18 of this manual before operating this machine.

Failure to do this may cause fire or electric shock.



Do not use this machine for the endless splicing of belt of other manufacturers.

Splice defects may occur if this machine is used for endless splicing of belts from other manufacturers.

This may reduce the function and performance of the belt, or render it unusable.

2. Confirmation of Product



Before operating the press, check that the product is exactly what you have ordered. Using this product other than those specified in this manual may cause fire, electric shock, injury or burn.

2-1) Confirmation of Product


On opening the package, confirm the following points.


- 1) Are descriptions on the nameplate the same as those of item ordered? Confirm the model and power supply specification.
- 2) Is there any breakage or anything missing?

 The package contains this manual, the press and power cable.
- 3) Have screws and nuts loosened during shipping?

We double-check all items during inspection and shipment of products. In the event of any defect or failure, please contact your local distributor, agent in your area or our company.

2-2) Confirmation of the nameplate





MODEL: Press model

INPUT: Input power supply specification and power consumption

S/N: Serial number

2-3) Press model

There are two kinds of models with a different input power supply. The specification of the power supply is described by the input.

2-4) Notes for inquiry

When making inquiries, please contact us with both the press model and serial number.

3. Specification

3-1) Outline of the press

(1) The NPS-2005 press is specially designed for the joining of NITTA's CFTG belts using 200mm long "fingers."

(2) This machine is applicable with the following belt endless splicing specifications.

Joint specification: Finger shape: 200 mm long × 10 mm pitch

Maximum belt width: 60 mm or less
Maximum belt thickness: 7.5mm or less

(3) Finger-endless splicing requires the finger puncher and pre-setter* of another-sales.

The pre-setter is required for each width belt that is to be made endless-spliced.

3-2) Main specifications of the Press

Model	NPS-2005-1	NPS-2005-2		
	100 - 120V	200 - 240V		
Input power supply	50 / 60Hz	50 / 60Hz		
	578 - 833W	578 - 833W		
Fuse	φ5.2 × 20mm 10A, 250V*			
Preset temperature	45 - 200°C**			
Outer dimension With the press closed: 301 mm wide × 300 mm long × 180 mm				
	With the press opened: 301 mm wide × 440 mm long × 266 mm high			
Weight	9.5 kg			

^{*} When replacing the fuse, use the article of the specification shown above.

This machine has been set to end cooling at 45°C of temperature. Hence setting the temperature to around 45°C may cause this machine to go standby without operating the cooling fan.

^{**} Cannot set outside the range of the preset temperature (44°C or lower, 201°C or higher).

4. Operation Environment

Ambient temperature	5 – 40°C (no dew condensation)
Ambient humidity	15 – 85%R.H.
Working place	Indoor (place without dust and water)
Atmosphere	No inflammable, combustible or corrosive gas and steam



Avoid using this machine in the following environment.

Failure to do this may cause fire or electric shock.

- In the environment of inflammable or combustible gas
- In the environment of corrosive gas
- In the ambient temperature of 5°C or below
- In the ambient temperature of 40°C or above
- In the environment of high humidity (humidity exceeds 85%)
- In the environment of wetting by steam, water drop or dew condensation, etc.

5. Storage Environment

Ambient temperature	5 - 40°C (no dew condensation)
Ambient humidity	15 - 85%R.H.
Working place	Indoor (place without dust and water)
Atmosphere	No inflammable, combustible or corrosive gas and steam



When not in use, store this machine under the above conditions. WARNING Poor storage conditions may cause mechanical disorders in the machine and may result in electric shock or fire.



When not using or carrying the machine, be sure to set the hook and turn **WARNING** the rotary handle until it slips. Insufficient clamping may cause injury.





Before operating the machine, be sure to conduct the prior-to-use inspection and confirm the normal performance.

In the event any abnormality is found in the prior-to-use check, please immediately contact your local distributor, agent in your area or our company.


6. Name of each Part

6-1) Left side view of the press





6-3) Temperature controller



7. Operation Procedure

7-1) Power ON

Connect the power plug to the socket correctly.

The power is supplied to the temperature controller. The controller indicates the present temperature (upper display) and preset temperature (lower display).



WARNING Be sure to connect to a grounded outlet.

7-2) Temperature setting (Temperature controller)

- 1) Check that the pilot lamp is off (no heating or cooling).
- Push the (para) display change button three times to indicate "SP-1" on the present temperature display. At this time, the preset temperature display indicates the preset temperature.

* The preset temperature before shipping is 185°C.

- Push the (\land) (up) button to raise the preset temperature or push the (\lor) (down) button to lower. Push the button once and the flickering figure increase or decrease 1°C each time.
- Pushing the (side) button shifts the figure of temperature.

 4) The figure of the preset temperature display is flickering when the figure of the temperature is adjusting.
 - The preset temperature will be fixed when no pushing is made for 2 sec or more.
- 5) Push the para display change button two times to return the present temperature display to the original state.

7-3) Hold time setting (Temperature controller)

- 1) Check that the pilot lamp is off (no heating or cooling).
- Push the (para) display change button four times to indicate "E1.on" on the present temperature display. At this time, the preset temperature display indicates the hold time (in sec).

* The hold_time before shipping is 300 sec.

Push the (v) (up) button to increase the time or push the (v) (down) button to decrease. Push the button once and the flickering figure increase or decrease 1 sec each time.

Pushing the (side) button shift the figure of hold time setting.

- 4) The figure of the hold time display is flickering when the figure of the hold time is adjusting.
 - The hold time setting will be fixed when no pushing is made for 2 sec or more.
- Push the (para) display change button once to return the present temperature display to the original state.

The indicator of temperature returns to the preset temperature.



Although changing the preset temperature and hold time is possible also CAUTION during heating or cooling, heating or cooling may become incorrect. Hence avoid changing the setting during heating or cooling since it may cause incorrect endless splicing.

7-4) Operation

- 1) To start operation, push the start switch for 0.5 sec or more.
- 2) On starting of operation, the pilot lamp lights and the heating of upper and lower heat plates start.
- 3) The machine operates in the sequence of; heating to the preset temperature, temperature holding (period previously set) and cooling. On completion of temperature holding, the pilot lamp goes off, and the machine operate the cooling fan until present temperature goes below 45°C.
- 4) When present temperature goes below 45°C, the cooling fan stops and the machine become a standby.



Be sure to wear heat-resistant gloves when operating the press. Failure to do this may cause burn.



An operator should not leave the machine in use. Take a measure to prevent other people from touching this machine unexpectedly. Failure to do this may cause burn on other people.

- 7-5) Discontinuing operation of the machine while in use
 Disconnect the plug if it becomes necessary to discontinue operation of the machine while it is
 in use.
 - * Even if the plug is disconnected during operation, preset data of preset temperature and hold time are maintained.



When operation is discontinued during use, the machine is kept at high temperature. Be sure to wear heat-resistant gloves when handling the machine.

Failure to do this may cause burns.



The operator should take measures to prevent other people from touching the machine accidentally, until the machine temperature lowers to near room temperature (about two hours).

Failure to do this may cause burns to others.




If machine operation is discontinued during the process of splicing a belt, do not use the belt.


The splice may become defective, reducing the function and performance of the belt, or rendering it unusable.


8. Endless Splicing Procedure

8-1) Required Tool



8-2) Belt setting







Description


- 3) Set the silicone sheet on the belt as shown in Fig. f.
 - * Remove any dust or foreign object on the silicon sheet before operation.
 - Change the sheet if deteriorated, scratched or torn.
- 4) Place the upper pre-setter over the silicone sheet as shown in Fig. g.
 - * The upper pre-setter has also marking lines. Place the upper pre-setter over the lower one while mating the marking lines.


8-3) Preparation of press



Figure/Photo







Description



This machine reaches a high temperature in operation. Wear heat-resistant gloves when carrying out the following works.

- Place the pre-setter prepared as described in section 8-2) Belt setting on page 13, between pre-setter guides as shown in Fig.
 - * Place the pre-setter at the center as much as possible.
 - * When placing, be careful not to pull out the belt from the pre-setter.
- 2) Gradually close the top cover so that the upper plate is positioned in parallel with the pre-setter.
 - * Quick closing the top cover may cause the pre-setter to shift its position or the belt to come off the pre-setter.
- 3) Set the hook and turn the torque limiter until it slips as shown in Fig. j.
 - Excessive turning will cause the handle to slip in removing also, disturbing easy removing.
- 4) Push the start switch to start endless splicing.
 - * It takes about 60 min to finish one cycle of operation (heating, temperature holding and cooling) with the presetting before shipping at 23°C of environmental temperature.
 - * The required time changes according to ambient environmental temperature or the setting of preset temperature or hold time of the press.
- 5) On completion of temperature holding, the pilot lamp goes off and operate the cooling fan. Check that the cooling fan has stopped after cooling completion before opening the top cover.
- 6) Take out the pre-setter and remove the upper one, silicone sheet and belt in order. Fig k
 - * Use the belt after it has cooled down to room temperature.

Figure/Photo	Description
Torque Limiter Hook Fig. I	7) To continue endless splicing, prepare the pre-setter by following the procedure of section 8-2) Belt setting and then repeat the procedure of section 8-4) Endless splicing. Be sure to wear heat-resistant gloves when operating the press. 8) To end operation, check that cooling is completed. Then set the hook and turn the torque limiter to lock before disconnecting the power plug as shown in Fig. I. Securely clamp the hook and rotary handle. Insufficient clamping may cause injury.

9. Troubleshooting

Problem	Cause		Solution		
The power plug has been disconnected.		Connect the power plug.			
No display on the temperature controller	The fuse has blown out.		Replace the fuse.		
	Is power supplied to the outlet?		Failure of the temperature controller or disconnection of power cable or internal wiring is suspected. * Please contact your local distributor, agent in your area or our company.		
		No	Supply power to the outlet.		
The temperature		1	Disconnect the power plug once and connect it again.		
controller gives a display starting with AL. (AL01 - AL99)	Defective data on temperature controller		* If the alarm display does not disappear, failure on the temperature controller is suspected.		
(ALOT - ALOS)			* Please contact your local distributor, agent in your area or our company.		
	Setting change is not possib 6 sec. right after power ON.	le for	Wait 6 sec. or more to make a setting.		
Temperature and hold time cannot be set.	The para and other buttons were pushed right after the preset value was changed.		To fix the preset value, avoid pushing buttons for 2 sec. or more.		
	Other than the above: Failure of the temperature controller		If setting is not possible even by the above methods, failure on the temperature controller is suspected.		
			* Please contact your local distributor, agent in your area or our company.		
	Does power supply not match the specification?		Use the correct power supply.		
Cannot be heated to the set temperature.			Failure of the temperature controller or disconnection of internal wiring is suspected.		
			* Please contact your local distributor, agent in your area or our company.		
			This machine has been set to end cooling at 45 °C. Setting the temperature to around 45 °C may cause the cooling fan to operate incorrectly.		
The cooling fan does not operate.	Has preset temperature been set to around 45 °C?		Set the preset temperature higher.		
not operate.		No	Failure of the cooling fan or disconnection of internal wiring is suspected.		
			* Please contact your local distributor, agent in your area or our company.		
The rotary handle slips and cannot be loosened.	The rotary handle was turned excessively.		Lightly tap the handle from the rear to the front with a plastic hammer while taking care not to give the press any strong jolts. * Throttling force is sufficient when the rotary handle begins to slip.		

10. Inspection

Check item	Date/check	Date/check	Date/check	Date/check	Date/check
The power cable have no flaw.					
The temperature controller is not damaged.					
There is no screw or part missing.					
The machine body is not damaged.					
Heat plates have no resin or foreign matter adhered.					
The pre-setter have no flaw.					
The pre-setter have no resin or foreign matter adhered.					
The hook or rotating handle have no distortion.					

^{*} Please make copies of this page and use them for daily check before use.

NITTA CORPORATION

4-4-26 Sakuragawa Naniwa-ku, Osaka 556-0022 Japan

http://www.nitta.co.jp

NITTA INDUSTRIES EUROPE GmbH

Hansaallee 201,40549 Dusseldorf_Germany Phone:49-211-537535-0 Fax:+49-211-537535-35 http://www_nitta_de

NITTA CORPORATION OF SINGAPORE PTE LTD 120 Lower Delta Road, #05-07/08

Cendex Centre, Singapore 169208 Phone:+65-6438-8738 Fax:+65-6438-8793 http://www.nitta.com.sg <Thailand Liaison Office>Phone:+66-9-0654-9717 <Indonesia Liaison Office>Phone:+62-878-2292-5633

TAIWAN NITTA FILTER CO.,LTD.
Headquarters: Chia Hsin Building 10FL Room No., 1005, 96 Chung Shan North Road Section 2, Taipei, Taiwan, R.O.C. Phone:+886-2-2581-6296 Fax:+886-3-469-0260 http://www_nitta_com_tw

NITTA BRASIL

Rua Francisco Mommenshon,50B,Galpão 02 Laranjeiras, Caieiras, São Paulo, Brazil Phone/Fax:+55-11-4441-2922 http://www.nitta.com.br

CONNECT CONVEYOR BELTING INC.

405 Industrial Drive Unit 3-8, Milton, Ontario Canada L9T 5B1 Phone:+1-905-878-5552 FAX:+1-905-878-0344 http://www.connectbelting.com/

Phone:+81-6-6563-1225 Fax:+81-6-6563-1242

NITTA CORPORATION OF AMERICA

7605 Nitta Drive, Suwanee, GA 30024, U.S.A. Phone:+1-770-497-0212 Fax:+1-770-623-1398 http://www.nitta.com

NITTA CORPORATION OF HOLLAND B.V. Berenkoog 25, 1822 B.H. Alkmaar, The Netherlands Phone:+31-72-5622234 Fax:+31-72-5613238 http://www.nitta.nl

NITTA (SHANGHAI) MANAGEMENT CO., LTD

Room2705, Shenggao International Building, No.137 Xianxia Road, Shanghai 200051 Phone:+86-21-6229-6000 Fax:+86-21-6229-9606 http://www.nitta-cn.com

NITTA CORPORATION INDIA PVT. LTD.

Gat No.186, Village Fullgaon, Taluka Haveli, Pune, Maharashtra 412216, INDIA Phone:+91-20-6731-3400 Fax:+91-20-6731-3401 http://www.nitta.co.in

NITTA CORPORATION KOREA OFFICE

Room710, 7F, ShinhanDM Bldg. Mapo-daero 25, Mapo-gu, Seoul, Korea Phone:+82-2-3274-1252 Fax:+82-2-3274-1253 http://www_nitta_kr

The specification is subject to change for improvement without notice.